


Assembly



Note: Always put compound back in container after play.

Product and colors will vary.

PLAY-DOH and the PLAY-DOH logo are trademarks identifying quality modeling compound products produced exclusively by Hasbro, Inc.

© 2013 Hasbro. All Rights Reserved.

TM & ® denote U.S. Trademarks.

U.S. Patent No. 6713624 and U.S. Patent Pending. PN 7393480000 A5013

Questions? Call: 1-800-327-8264



Double Desserts™

AGES
3+



Adult assembly required.

NOTICE TO PARENTS: CONTAINS WHEAT. NONTOXIC. CONFORMS TO ASTM D-4236.


CONTENTS: Playset base, oven, oven top, 3 oven molds, 2-piece extruder, server, scoop, roller, 2 plates, instructions, 2 cans of PLAY-DOH® Brand Modeling Compound and 2 cans of PLAY-DOH PLUS compound.

Fun to play with, but not to eat.


See back panel for assembly instructions.

Play Make a PLAY-DOH treat!


1 Choose a mold!




2 Slide mold into oven.



3 Load!




4 Press!



5 Decorate!

Shape fun details!



Add PLAY-DOH PLUS frosting!

How to use your PLAY-DOH® PLUS Compound!

What's the difference?

Classic PLAY-DOH compound:

- Best for rolling, cutting and shaping in molds.
- Shape a pretend cake in the "oven," scoop imaginary ice cream, and mold decorations!



PLAY-DOH PLUS compound:

- Best for placing in extruders to press out compound.
- Press out pretend frosting and whipped cream!



Cleaning:

Remove the excess compound from the tools and accessories. Allow the remaining compound to dry, then scrape or vacuum it away.