



AGES 14+

NERF
RIVAL
PRECISION BATTLING



OVERWATCH

WARNING:
Face mask is not a protective device.



***"YOU LOOK
LIKE YOU'VE
SEEN A GHOST."***



REAPER

HANDLE

TRIGGER

FOR USE WITH NERF RIVAL
PRODUCTS ONLY.




Product and colors may vary. Retain this information for future reference. © 2018 Blizzard Entertainment, Inc. All rights reserved. All trademarks referenced herein are the properties of their respective owners. ® and/or TM* & © 2018 Hasbro, Pawtucket, RI 02861-1059 USA. All Rights Reserved. TM & ® denote U.S. Trademarks. EC & UK Reg. Des. Apps. US/Canada TEL. 1-800-255-5516 E31119 PN00039389

BLIZZARD
ENTERTAINMENT




LOAD & FIRE

1 Move trigger lock to unlock.





2 Pull handle all the way back.





3 Load.

x8 MAXIMUM ROUNDS




4 Move handle all the way forward. Ready indicator will appear on side of blaster. Blaster is primed when ready indicator is visible.




READY INDICATOR

5 Pull trigger to fire 1 round. To fire another round, move handle all the way back and all the way forward, then pull trigger to fire.



TRIGGER LOCK

On side of blaster, move trigger lock down to lock trigger and up to unlock. Always put the trigger lock in locked position when blaster is not in use and when storing blaster.



LOCKED

RESET BUTTON

Push down and hold reset button and pull handle all the way back. Remove any jammed rounds. Make sure you aim the blaster away from you and anyone else while releasing jammed rounds.

