



NERF
RIVAL
PRECISION BATTLING



TO AVOID EYE INJURY:
⚠ **WARNING:** Do not aim at eyes or face.
Use of eyewear recommended for players and people
within range. Use only official Rival rounds. Other rounds
may not be safe. Do not modify rounds or blaster.

*"IT'S HIGH
NOON
SOMEWHERE
IN THE
WORLD."*



McCREE


BARREL

SLIDE

SPUR

TRIGGER

FOR USE WITH NERF RIVAL
PRODUCTS ONLY.




Product and colors may vary. Retain this
information for future reference. © 2018
Blizzard Entertainment, Inc. All rights
reserved. All trademarks referenced herein
are the properties of their respective owners.
®* and/or TM* & © 2018 Hasbro, Pawtucket,
RI 02861-1059 USA. All Rights Reserved. TM & ®
denote U.S. Trademarks. EC & UK Reg. Des. Apps.
US/Canada TEL. 1-800-255-5516
E3121 PN00055469



BILZARD
ENTERTAINMENT




LOAD & FIRE



- 1 Move trigger lock to unlock.




- 2 Move slide all the way back.




- 3 Insert round in just until you feel resistance, then stop.

x1 MAXIMUM ROUND

- 4 Move slide all the way forward. Ready indicator will appear on side of blaster. Blaster is primed when ready indicator is visible.




- 5 Pull trigger to fire. Repeat steps 2-5 to load and fire another round.




Always use the slide to open and close the barrel.

TRIGGER LOCK

On bottom of blaster, move trigger lock as shown to lock it. Always put the trigger lock in locked position when blaster is not in use and when storing blaster.




LOCKED




RESET BUTTON

Push down and hold reset button and pull slide all the way back. Remove any jammed rounds. Make sure you aim the blaster away from you and anyone else while releasing jammed rounds.



1



2

3