


PLAYSKOOL®

OVER 18M - 4YRS

IMPORTANT! PLEASE READ
INSTRUCTIONS COMPLETELY
BEFORE USING TOY.



123

SESAME STREET®

SINGING ABCs ELMO



**Press Elmo's tummy
to hear him talk and
sing about the ABCs!**

English to Spanish Mode:


**To switch Elmo's speech from English to Spanish,
follow these steps:**

- Press and hold Elmo's tummy for 3 seconds.
- You will hear a beep and Elmo will speak a phrase in Spanish.
- Release your hold on Elmo's tummy **before** he finishes speaking to remain in Spanish mode.
- If you release your hold on Elmo **after** he finishes speaking and you hear a beep, he will revert to English mode.
- Repeat steps to switch Elmo back to English mode.

To Replace Batteries:

2X 1.5V AA ALKALINE BATTERIES

Replace demo batteries with alkaline batteries. Use a Phillips/ cross head screwdriver (not included).



Troubleshooting:

If Elmo doesn't talk or make sounds, it may be time to replace the batteries.

IMPORTANT: BATTERY INFORMATION


Retain this information for future reference. Batteries should be replaced by an adult.

⚠ CAUTION:

TO AVOID BATTERY LEAKAGE

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and – polarity markings.
2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short-circuit the supply terminals.
6. **RECHARGEABLE BATTERIES:** Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.**

Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.



Song Lyrics

If little ones would like to sing along with Elmo, this is what he sings:

**A, B, C, D, E, F, G, H, I, J, K, L, M, N, O, P, Q, R, S, T, U,
V, W, X, Y, Z. Now our ABCs are done, singing the
alphabet's so much fun!**

FCC STATEMENT: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAN ICES-3 (B) / NMB-3 (B)

Discover, grow & play with Playskool Friends!

www.Playskool.com/SesameStreet

Product and colors may vary. Retain this information for future reference.

Sesame Street® and associated characters, trademarks, and design elements are owned and licensed by Sesame Workshop. © 2018 Sesame Workshop. All Rights Reserved.

®* and/or TM* & © 2018 Hasbro, Pawtucket, RI 02861-1059 USA. All Rights Reserved.

TM & ® denote U.S. Trademarks. US/CANADA TEL. 1-800-255-5516

E3340 PN00058703

