





 **WARNING:**
CHOKING HAZARD—Small parts.
Not for children under 3 years.


3+



Connect nozzle
to hose.



Insert nozzle
into sheet.




Place sheet flat on
a level surface.


Turn on hose. Use
a **SLOW FLOW** of
water. Keep sheet
flat while filling.

Adult
assembly
required.

NOTE




It is normal for some water to leak from the center channel.



If any pods start to stretch, remove nozzle and turn water off to prevent overfilling or bursting.

TIP

If any pods aren't filling, keep pulling the sheet flat. Make sure sheet is **ALWAYS** lying flat while filling it.



Remove nozzle from sheet and turn off hose.



Pull apart at perforations to remove pods from sheet.

CAUTION: Do not aim at eyes or face. TO AVOID INJURY: Use only clean tap water.

Keep away from pets.

NERF, BETTER THAN BALLOONS, and HASBRO and all related trademarks and logos are trademarks of Hasbro, Inc. © 2024 Hasbro. TM & ® denote U.S. Trademarks. Hasbro, Pawtucket, RI 02861-1059 USA. US/CANADA TEL. 1-800-255-5516.

F8742, F8743, F8746, F9007
PN00092901 U.S. Pat. Pend.